
## **Hard Wire Connection**

If it is necessary to hard wire this appliance, a qualified electrician must remove the cord connection, and wire the appliance directly to the house hold wiring.

This appliance must be electrically connected and grounded in accordance with local codes, if hard wired. In the absence of local codes, use the current ANSI/NFPA 70 NATIONAL ELECTRICAL CODE in the United States or the current CSA C22.1 CANADIAN ELECTRICAL CODE in Canada.





- A. Remove the cover plate from the right side bottom of the appliance by removing the three screws, as shown above. Save screws for installation of new cover plate.
- **B.** Remove the wire connectors from the power cord. Keep power cord, in case needed in future.
- **C.** Remove the power cable and wires from the cover plate. Thread your wiring through the hole in the cover plate for connecting to the wires in the Sideline® fireplace.
- Using the wire connectors, connect the ground green wires (G), the common white wires (N)together, then the hot black wires (L) and then the refer to Figure 3.
- **E.** Reinstall the cover plate using the three screws, as shown in Figure 1.

