

Operating the TV Lift

Plug the TV lift control box into a nearby wall outlet. The lift will automatically retract to the lowest position and be ready for you to start programming the lift as desired.

Raising/Lowering the Lift

1. Using the wireless remote that comes with your cabinet, you can raise and lower the lift.
2. The height you set using the manual switch (above) will be the default maximum height that the lift will go to using the wireless remote.
3. Except for the manual switch, all other input devices (universal remotes, 12V trigger, RS-232, IR remotes, etc) will only operate the lift within the pre-set ranges that were programmed above using the manual switch.
4. To raise the TV, press the "UP" button on your wireless remote
5. To lower the TV, press the "DOWN" button on your wireless remote
6. To stop the lift when it is either going up or down in the set range, simply press either the "UP" or "DOWN" button on the wireless remote and the lift will stop immediately.

Setting the Lift Height

1. Make sure the lift is at the lowest position, fully down.
2. Locate the manual switch inside the cabinet.
3. Press the "UP" button on the manual switch
4. When the lift reaches the desired height for optimum viewing and comfort for you, press either the "UP" or "DOWN" button on the manual switch and the control box will memorize and store that height.

Connecting Components

The control box comes equipped with 2 switched AC receptacles that you can plug components into.

If you choose to use the outlets, please note that each time you raise or lower the lift, any component plugged into the outlets will be powered on or off.

For certain components that may have long reboot/restart times such as Cable Boxes, Satellite Receivers, or DVRs, you may find it more efficient to plug those components directly into the wall outlet or into a power strip that sits on the floor of the cabinet.