

**Encase Fireplace Mantel**  
**Model # : 90011, 90012, 90021, 90022**

**INSTALLATION MANUAL**



**! WARNING**

**Read and understand** this entire installation manual, including **all safety information**, before mounting the mantel on the wall. Failure to do so could cause the mantel to not be secured to the wall properly.

**! CAUTION**

**Keep this installation manual** for future reference. If you sell or give this product away, **make sure this manual accompanies this product.**



**PREMIUM  
ELECTRIC FIREPLACES  
& TV LIFTS**

Exceeding Expectations

Table of Contents

Unpacking Your Encase Fireplace Mantel..... 3

*Parts and Hardware* ..... 3

    Tools Required..... 3

    What’s Included in the Box ..... 3

Installation ..... 4

*Choosing Installation Location*..... 4

*Installing Mounting Blocks*..... 4

*Mounting The Encase Fireplace Mantel*..... 6

Warranty ..... 8

IMPORTANT SAFETY INFORMATION  
WARNING!

- Make sure to use the appropriate tools listed in this manual for installing your Encase Fireplace Mantel.
- The maximum weight limit for the Encase Fireplace Mantel is 50lbs. Do not exceed the maximum weight listed.
- Wear proper protective gear when installing your Encase Fireplace Mantel.
- Follow good construction practices when installing your Encase Fireplace Mantel.
- Thoroughly read through the installation instructions to familiarize yourself with the process before beginning installation.
- Before installation acclimate the mantel to the room for at least 24 hours.






# Unpacking Your Encase Fireplace Mantel

## Parts and Hardware

### Tools Required

- Power Drill and Drill Bits
- Stud Finder

### What's Included in the Box

	
Mantel - 1	
	
Mounting Blocks - 2	Mantel Touch-up Paint – 1
	
2 ½" Screws For Wall Mounting - 4	2" Screws For Securing Mantel to Mounting Blocks – 4

\*\*NOTE: Longer screws may need to be used for securing the mounting blocks to your wall depending on the surface of your wall.

## Installation

### Choosing Installation Location


- If mounting above a Touchstone Home Products Electric Fireplace, measure wall location so that location for mounting the Encase Fireplace Mantel meets the recommended clearances.
- Minimum clearances (measurements taken from front of glass panel):

<b>Touchstone Wall Mounted Fireplace:</b>	24" from top of fireplace to bottom of mantel
<b>Touchstone Recessed Fireplace:</b>	12" from top of fireplace to bottom of mantel

### Installing Mounting Blocks

#### Instructions:


1. Using a stud finder, locate 2 framing studs on the wall which you intend to mount the mantel.



## Installing Mounting Blocks – cont.


2. Once you have located 2 studs, mount the 2 mounting blocks on the wall using 2 2 ½” screws provided per each mounting block.

**\*\*NOTE:** Longer screws may need to be used for securing the mounting blocks to your wall depending on the surface of your wall.




## Mounting The Encase Fireplace Mantel

1. After the mounting blocks are securely mounted on the wall, center the mantel over the mounting blocks.



## Mounting The Encase Fireplace Mantel – cont.

2. Once the mantel is centered over the mounting blocks, use 4 2” screws provided to secure the mantel to each mounting block.



3. Once secured, your mantel is now ready for use.

NOTE: The maximum weight that the mantel can support is 50lbs.

## Warranty

Touchstone Home Products®, Inc warrants our Encase Fireplace Mantel to be free of defects in material and workmanship for one year from date of purchase. Touchstone will replace any Encase Fireplace Mantel that is deemed defective or becomes defective during normal use within one year after the date of purchase.

Touchstone Home Products®, Inc does not warrant its products against damage caused by third parties.

Touchstone Home Products®, Inc does not cover damages caused by misuse, alterations, accident, lack of maintenance, abuse or neglect.

The warranty does not cover paint scratches, cosmetic blemishes, dents, corrosion, or other normal wear and tear associated with the fireplace. Damage to the Encase Fireplace Mantel due to water, weather damage, long periods of dampness, condensation, damaging chemicals or cleaners are not covered under warranty.

Touchstone Home Products® will not be responsible for installation, labor, or any other expenses related to the reinstallation of a warranted part, and such expenses are not covered under warranty.

Extended warranty coverage for the fireplace is available by contacting Touchstone Home Products® directly at 1-800-215-1990.



For immediate help with assembly, product information,  
or if your product arrives damaged, call our toll-free number at

**800-215-1990**

or email:

[customerservice@thpus.com](mailto:customerservice@thpus.com)

**Our staff is ready to provide assistance.**