



Bluetooth Speaker Setup

The AudioFlare™ series recessed fireplace comes with a Bluetooth speaker installed inside the fireplace, allowing the user to connect their favorite mobile device to the fireplace. Users can stream media stored locally on their mobile device or from their favorite streaming service direct to the AudioFlare™ series recessed fireplace.



Bluetooth Speaker Connection Instructions:

1. Turn ON the AudioFlare™ series recessed fireplace. A “TINKLE” sound will play signifying that the fireplace has power and is ready for connection.
2. Make sure the Bluetooth feature on the mobile device is enabled and search settings for Bluetooth Connection.
3. Under the Bluetooth Connection options, the item **BLUETOOTH** should appear. This is the Bluetooth speaker inside of the fireplace.
4. Connect to the **BLUETOOTH** speaker option and a “DING” sound should play from the speaker once connected.



5. The Bluetooth speaker is now ready for use. Volume is controlled through the user's mobile device.