

Reinstalling Outer Trim Pieces – Sideline Elite Series Fireplace

Tools Needed:


- Phillips Screwdriver

Instructions

1. Turn Off Sideline Elite Fireplace
2. Remove fireplace from wall and unplug the fireplace.
3. Looking at the fireplace from the back, remove the 4 screws holding the trim pieces in place on the left side of the fireplace.



4. Remove the 4 screws holding the trim pieces in place on the right side of the fireplace.



Top/Bottom Trim Pieces

Remove the screws securing the top/bottom trim pieces to the fireplace as shown below:



Top of Fireplace



Bottom of Fireplace

Side Trim Pieces

Remove the screws securing the side trim pieces to the fireplace as shown below:



Left Side of Fireplace



Right Side of Fireplace

****If you have any questions, contact the technical support department at Touchstone Home Products at 800-215-1990 option 3.**