

Paining the Touchstone IR Remote

Compatible Lifts:

- 23101 – SlimLift PRO
- 23401 – Whisper Lift II PRO
- 23501 – Whisper Lift II PRO
- 23601 – Whisper Lift XL PRO

Parts Needed:



23404 – WL2PRO RF Remote



23412 – WL2PRO IR Remote



WL2PRO Control Box



WL2PRO IR Sensor

touchstone

Instructions:

1. Press and hold the **LEARNING BUTTON** on the control box until the light starts to flash and let go of the button. The light will flash 3 times and turn off.



2. To pair the Touchstone IR remote to the lift, do the following for UP and DOWN functions:

UP:

1. Press the **UP** button on the Whisper Lift II PRO RF wireless remote. The red light on the control box will flash once and turn ON.

2. With the Touchstone IR Remote Control, aim the remote at the IR Sensor attached to the control box and press the **UP** button on the Touchstone IR Remote Control.

3. Once complete, move to the next command.



touchstone

DOWN:

1. Next, press the **DOWN** button on the Whisper Lift II PRO RF wireless remote. The red light on the control box will flash once and turn ON.

2. With the Touchstone IR Remote Control, aim the remote at the IR Sensor attached to the control box and press the **DOWN** button on the Touchstone IR Remote Control. Once recognized, the light on the control box will flash once.

3. Once complete, move to section 3 listed below.



3. Once you have paired the UP and DOWN commands to the Touchstone IR Remote Control, press and hold the **LEARNING BUTTON** on the control box until the light comes on. The light will flash 3 times and stay on. Pairing is now complete. You can use your Touchstone IR remote to control the Touchstone Home Products Whisper Lift II PRO TV Lift.

touchstone