



Dear Valued Customer,

Enclosed, you will find your replacement SRV/ValueLine TV Lift Mechanism. Included with the lift, you will find a new control box and wired controller. Please use these parts with the new lift mechanism that you received. **DO NOT USE THE ORIGINAL CONTROL BOX AND WIRED REMOTE** with the new lift mechanism. Please return all defective parts with the enclosed return label.

Enclosed, you will also find instructions for calibrating the lift prior to initial use and pairing the wireless remote control to the new control box.

If you have any questions, please contact our technical support department at 800-215-1990 option 3.

Thank you!

Brian Milito

Technical Support Lead

Touchstone Home Products

## Instructions for Calibrating SRV/ValueLine TV Lift

1. Plug in the lift cable to the control box.
2. Plug the lift cable into the new lift.
3. Plug in the wired controller to the control box.
4. Plug in the power cable to the control box.
5. With power applied to the lift, the read out on the wired controller should show as follows:

30003 ValueLine 2800: 27.1

32800 SRV 2800: 27.1

30004 ValueLine 3900: 31.5

33900 SRV 2800: 31.5

6. Press and HOLD the DOWN arrow on the wired controller. HOLD the DOWN arrow until the read out on the wired controller reads RES and the lift starts to move. Once the lift starts to move DOWN, release the DOWN button on the wired controller and the lift will reset.

7. The lift is now ready for use.

## **Pairing Wireless RF Remote To Lift**

1. Remove power from the lift
2. Grab the RF remote and hold in one hand.
3. Plug power back into the lift and within 5 seconds of applying power, press the UP button on the RF remote to pair the remote to the lift. If paired successfully, you will hear 2 sets of beeps, signifying that the remote is paired to the control box and lift.

The wireless RF remote control should now be operational.